



HB-10 Family Grows...

All HUTH benders are rugged I-Beam construction with a 5-HP motor that provides 58,000 pounds of bending power – more than enough for 3" tubing. The heavy-duty swager/expander gives you complete end-finishing capabilities.



HB-10

Model 1600 w/028 Die Package

- "Entry Level" Bender
- Manual Depth-of Bend Indicator
- Complete Manual Control
- Welded Cylinders/Ag Cylinders
- Flat Tool Tray



HB-2806

Model 2806 w/028 Die Package

- "The Work-Horse of the Exhaust Shop"
- Automatic Depth of Bend Indicator
- Push Button Control
- Ag Cylinders
- Flat Tool Tray



HB-2008

Model 2008 w/028 Die Package

- "Top of the Line" Deluxe Bender
- Automatic Depth-of-Bend Indicator
- Industrial Main Cylinder
- Auxiliary On/Off Switch
- Deluxe Die Trays

HUTH, Division of Hartford Benders, Inc.

PO Box 270467

260 Grant St.

Hartford, WI 53027

800-558-7808



Huth is excited to announce that the popular HB10 die package, **028** has been combined with the 2806 and 2008 model benders. Great benders and great tooling along with HB package pricing makes our Huth family of benders even better.

Call for details.

800-558-7808

028 PACKAGE **
INCLUDES:

5530	5" Rad Die 3"	556	Female Ball Die 2-1/4" - 2-1/2"
5412	5" Rad Die 2-1/2"	550	Male Ball Die 1-3/4": Swage 2"
5414	5" Rad Die 2-1/4"	552	Male Ball Die 2" : Swage 2-1/4"
5200	5" Rad Die 2"	553	Male Ball Die 2-1/4": Swage 2-1/2"
4414	4" Rad Die 2-1/4"	554	Male Ball Die 2-1/2": Swage 2-3/4"
4200	4" Rad Die 2"	112	Swage Die 1-1/2"
3134	3" Rad Die 1-3/4"	134	Swage Die 1-3/4"
3112	3" Rad Die 1-1/2"	508	Arbor
1350	Full Back Shoes 3" (2)	498	Arbor Tip, Small
4412	Full Back Shoes 2-1/2" (2)	499	Arbor Tip, Large
4211	Full Back Shoes 2-1/4" (2)	473	Segment 1-3/8" - 1-3/4"
1200	Full Back Shoes 2" (2)	474	Segment 1-3/4" - 2-1/8"
1134	Full Back Shoes 1-3/4" (2)	475	Segment 2-1/8" - 2-1/2"
1112	Full Back Shoes 1-1/2" (2)	476	Segment 2-1/2" - 3"
4410	Half Shoe 2-1/2"	97050	Die Spring
4416	Half Shoe 2-1/4"	870	O-Ring Kit
1045	Half Shoe 2"	815	Die Holder (853)
1040	Half Shoe 1-3/4"	816	Die Holding Pin
1038	Half Shoe 1-1/2"	855	Die Pins (Qty 30)
1750	Collet 2-1/2"	1079	Full Shoe Spacers (2)
1725	Collet 2-1/4"	1080	Half Shoe Spacer
1720	Collet 2"	97305	Huth Instructional DVD
1734	Collet 1-3/4"		
1712	Collet 1-1/2"		
853	Flare Tool		
557	Domer Die 1-3/4" - 2-1/2"		
558	Domer Die 2-5/8" - 2-3/4"		
555	Female Ball Die 1-3/4" - 2"		

** The HB-10, HB-2806 and HB-2008 come only with the 028 die package, NO SUBSTITUTIONS; however, additional tooling can be added to order.